



ELBA

DESIGNER HOOD
MODEL: FORZA EH-A9022ST(SS)

Owner's Manual

Please read this manual carefully before operating your set.

Retain it for future reference.

Record model number and serial number of the set.

See the label attached on the set and quote this information to your dealer when you require service.

For The Warranty Terms & Conditions, Please Refer To Warranty Certificate

Please read this instruction carefully. It is advisable to keep this instruction manual in a safe place for future reference.


SAFETY PRECAUTIONS

- 1.** Keep electrical appliances out of reach from children. Do not let them to operate the appliances without supervision.
- 2.** To protect against the risk of electrical shock, do not immerse the product, cord or plug into water or any other liquid.
- 3.** This product is for household and indoor use only.
- 4.** This product is not intended for use by person (including children) with reduced physical, sensory or mental capabilities unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 5.** If the power cord or plug is damaged, it must be replaced by the service centre or a qualified service technician to avoid hazard.
- 6.** Before installation, check if the mains supply voltage is matched with the voltage stated on the rating plate of the hood.
- 7.** There must be adequate air ventilation of the room when the cooker hood is used with the cooking appliances with burning gas or other fuels.
- 8.** Ensure that the installation of exhaust complies with the standard of local building, gas and electrical authorities.
- 9.** Do not ignite flames in the pans.
- 10.** There is a risk of fire if cleaning is not carried out in accordance with this instruction.

ASSEMBLY INSTRUCTIONS


Please check the following before installation:

- Installation of hood must be carried out by an authorized or qualified technician.
- For optimum air extraction, avoid having too many windows surrounding the cooker hood which will cause air convection.
- Make sure the hood is in level after installation to avoid oil spill over from the oil cup collectors.
- The optimum height for the installation is between 300 to 350mm which measure from the bottom of the hood to the top of the hob.








- 1) Before installing, determine the height between the bottom of the cooker hood to the top of the hob.
- 2) Mark the wall to suit all bracket locations.
- 3) Drill 4 holes with diameter of $\text{Ø}10\text{mm}$ and 60mm deep. Insert the screw anchors into the holes. Tighten the screw with the mounting bracket.
- 4) Hang the hood on the mounting bracket and make sure the hood is in level.
- 5) Fix the exhaust ducting on the hood with the screws provided.
- 6) Install the telescopic exhaust cover to the height required.
- 7) Install the oil cups on the cooker hood.
- 8) Before connecting to the mains supply, ensure that the mains voltage corresponds to the voltage on the rating plate inside the cooker hood.

PRODUCT DESCRIPTION



1. On/Off Button – To switch the cooker hood in standby mode and turn off the cooker hood.
2. Fan Delay Off Function – Press this button to schedule a delay to turn off the cooker hood.
3. LED Light Illumination – To switch on/off the LED light.
4. Normal Fan Speed – Press this button to activate normal fan speed.
5. High Fan Speed – Press this button to activate high fan speed.

OPERATING INSTRUCTIONS

1. Press the  button and press the  button to operate the cooker hood in normal speed. Press the  button to operate the cooker hood in high speed.
2. When the motor is running, press  button to turn off the cooker hood. (This function does not relate to the LED illumination)
3. Press the  button to turn on the LED light of the cooker hood. Press again to turn off. (This function does not relate to the cooker hood motor)

CLEANING AND MAINTENANCE

- The hood must always be disconnected from the electricity supply before carrying out the maintenance.
- Clean the hood with damp cloth with hot water and mild detergent. Do not use chemical, steel, wooden or abrasive cleaners to clean the hood.
- Clean the oil cups when they are more than half filled to avoid the oil from spilling.
- Remove the filter, wash in hot soapy water, dry and fit back into the hood. Do not use the hood without the filter installed.

MAIN SPECIFICATION

Rated Voltage : 220-240V/50Hz

Light : 2W x 2

Suction Power : 1,200m³/hr

Motor Power : 220W

Product Dimension : 900mm(W) x 940-1340mm(H) x 399mm(D)

NOTICE

This product must not be disposed together with domestic waste. It has to be disposed at an authorized place for recycling of electrical and electronic appliances. By collecting and recycling waste, you help to save natural resources and make sure the product is disposed in an environmental friendly and healthy way.



ELBA